Login

- 1. Lift the receiver and dial 99
- 2. Enter your extension number
- 3. Enter the first five characters of your password
- 4. Press 1 when prompted

To enter your password from the phone's keypad: press once an alphanumeric key corresponding to a letter which you need to enter; press the star button (*) to enter any special character.

Example: Password: 4Ag7\$Zl@ Enter: 4247*



BLF / Function keys

Function keys must be set up in Collaboration Settings -> Function keys or by the PBX administrator.

This phone supports up to16 Function keys distributed over 2 pages. Use **Navigation keys** to move between pages.

Make a call

Enter the number and press Send Soft key.

To switch between speaker mode and handset mode during a call: press **Speaker** key. To switch between speaker mode and headset mode during a call: press **Headset** key.

Dial a user for whom you have assigned a *Colleague* Function key: press the corresponding **Function key**.

<u>Call from call history:</u> press **History** Soft key from idle and select the number using **Navigation keys**, then press **Dial** Soft key.

Call from Phonebooks

- 1. Press Phonebook key.
- 2. Press **Filter** Soft key and select the phonebook
- 3. Press **Search** Soft key to search this phonebook and enter the name or phone number
- 4. Press Enter Soft key and select the contact using Navigation keys
- 5. Press Dial Soft key

Phonebooks must be set up by user via Collaboration or by the PBX administrator.

Mute the microphone during a call

Press Mute key to mute / unmute the microphone.

Hold / Second call

Press Hold Soft key during a call to put a call on hold.

Press **New** Soft key to make a second call, then enter the number manually or press **Select** Soft key to search for the contact in call history / in phonebooks.

Call transfer

<u>Blind transfer</u> (the desired party/extension is not notified of the impending transfer)

- 1. Press **Transfer key** during a call (the call is put on hold)
- 2. Dial the desired party/extension
- 3. Hang up

Colleague

Blind transfer via *Colleague* BLF / Function key: make sure *Direct transfer* option is enabled for this Function key in Collaboration:

👁 🚸 🔶 Dimitri

• Press the corresponding Function key during a call

Attended transfer (the desired party/extension is notified)

- 1. Press Transfer key during a call (the call is put on hold)
- 2. Dial the desired party/extension
- 3. Notify the third party of the impending transfer
- 4. Hang up to transfer the call

<u>Attended transfer via Colleague BLF / Function key</u>: make sure *Direct transfer* option is disabled for this Function key in Collaboration:



- 1. Press the corresponding **Function key** during a call (the current call is put on hold)
- 2. Notify the third party of the impending transfer
- 3. Hang up to transfer the call

Conference

- 1. Press **New** Soft key during a call (the call is put on hold)
- 2. Make a second call to the contact you would like to invite to the conference call
- 3. When the third party answers, press **Conference** Soft key.

Access Voicemail

- 1. Press Voicemail key
- 2. If requested, enter the first five characters of your password
- Select the message and press Play Soft key to listen to it; press Info Soft Key for more information or to delete the message.

Call Features

Press **Features** Soft key from idle to set the following call features for each call type (Internal, External, Blacklist, Whitelist), based on user status (Available, DND, Away): Call reject, Call forwarding, Call Waiting, Mobility, Ring Tone.

Features can be also set up in Collaboration Settings -> Features.

User Guide WP480G





Packing list

- 1 x WP480G phone
- 1 x handset
- 1 x handset cord
- 1 x stand

Safety information

https://www.wildix.com/safety-information/

Mounting instructions

Attach the stand to the phone (desk mounting); for wall mounting, use wall mount bracket (article can be purchased separately, code: WallMount)

Keypad instruction



Connection

The ports are situated on the rear panel of the phone

- Connect the handset to the port using the handset cord
- Connect the phone to the network PoE switch using RJ-45 cable
- (Optional) Connect the port to the PC using RJ-45 cable
- (Optional, this is a PoE device) Connect the phone to the power supply (power adapter can be purchased separately)
- (Optional) Connect the headset to the port (headsets can be purchased separately)
- (Optional) Connect the EHS headset adapter (adapter can be purchased separately, code: WPEHS)



LED indicator

Flashing: Incoming call / Missed call / New Voicemail Off: In the standby mode

0

 $[\Box]$

Internet

PC

R

þ

Ext

 \bigcirc

BLF / function keys

Note: set up Feature keys in Collaboration Settings; these keys can be used to place a call / pickup / transfer a call

Soft keys

confirm operations indicated on the screen select options indicated on the screen

Navigation keys

navigate the menu confirm different options by pressing the central Key move between the pages of BLF keys

Voicemail key

Phonebook key

Speaker key

Mute key

Volume keys

full guide online:



www.wildix.com