Wildix W-AIR 70

Simple user guide

Everyday calls, transfers and voicemail.
For a handset already set up by your installer.



Before you start
Charge the handset in its cradle. The W-AIR 70 connects to a W-AIR DECT base station; it does not join your office Wi-Fi directly.

Everyday essentials

Make or answer	Dial a number, then press the **green call key**. Press green to answer.
End a call	Press the **red hang-up key**.
Speakerphone	During a call, press the **green call key** to switch speaker mode.
Volume and mute	During a call: **Up / Down** adjusts volume; **Left** mutes or unmutes.
Hold and resume	Press **Hold**; press **Retrieve** to return to the caller.
Call history	Open **Menu > Calls**, select an entry, then press green.
Voicemail	Press and hold **1**; follow the prompts. Have your voicemail PIN ready.

Soft keys are the two buttons below the screen. Their current actions appear on the display.

Transfer after speaking to a colleague

Press **Transfer** or **Hold**. Dial the extension and press green. When your colleague answers, introduce the caller, then press **Transfer**.

Transfer without speaking first

Press **Transfer**, dial the extension, then press **Transfer** again.

Need help? Move nearer the base if signal is weak. If the phone will not ring, check silent mode and ring volume. For registration, voicemail or calling problems, contact Excel.

0800 711 7111 | info@excelcomms.co.uk | www.excel-comms.co.uk

Key labels and voicemail access can vary with your system setup.

Handset instructions: Wildix W-AIR 70 manual. Logo and handset image: Excel Communications.